

# LOCK'ER<sup>®</sup> DOWN

## INSTALLATION INSTRUCTIONS

### LD3002

[SUVault® Model 2000 to 2014 LD3002 Escalade, Suburban, Tahoe, Yukon, Yukon XL]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Remove the **3<sup>rd</sup> row** seats from the rear of the vehicle.
3. Remove the **2** cargo anchors near the rear of the vehicle.
4. Place the safe in the rear of the vehicle, then use the LOCK'ER DOWN PROVIDED 13mm LONG BOLTS to secure the safe to the vehicle.
  - a. The long bolts fit through the slotted holes in the bottom of the safe, and fit into the holes from the removed anchors in **Step 3**.
5. Enjoy your purchase!

### Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 13mm socket Bit

**Contents Included:** **2** 13mm Long Bolts.

